

 **Mórgan®**

 **Mórgan®**

Market Expansion
Services by
www.dksh.com.my



DKSH

E-mail: electrical.appliance@dksh.com
www.morgan.my

 [facebook.com/morganappliances](https://www.facebook.com/morganappliances)

USER MANUAL



Juice Extractor

MJE-SC160W

OPERATING INSTRUCTIONS

JUICING

1. Before using, ensure that the power button of the appliance is switched to OFF position to prevent any accident or injuries.
2. Before juicing, first ensure juicing net and rotor are correctly assembled, and no hard contact exists between juicing net cutter and transparent cover. Put the transparent cover on, put the handle into the cover slot and turn the machine ON.
3. Assemble according to the diagram of "name and position of main components". Turn power on and allow to operate without load for 5 seconds. Place prepared vegetables or fruits into feed port of the juicer, using the pusher to feed them in.
4. Note: when pressing food using the pusher, do not use more than 1 kg of sudden force otherwise juicing performance will be affected.

OPERATING TIMES

1. This machine is designed with button switches of different speeds (O for stop, I for normal speed, II for strong speed).
2. For juicing, select strong speed.
3. Use for 1 minute and stop for another minute before continuing to use again.
4. Stop for 15 minutes after operating as no.3 above to allow the motor to cool down and extend the machine's service life.

C O N T E N T S

4 Parts Identification

4 Specifications

5 Features

5 Important Safeguard

6 Operating Instructions


7 Warning

7 Cleaning And Maintenance

Please read this Instruction Manual carefully before using it, and please keep the instruction manual for future reference. We believe our easy-to-use juice extractor will make your life comfortable and more pleasurable.

PARTS IDENTIFICATION

1. Pusher
2. Transparent cover
3. Juicing net
4. Middle ring
5. Handle
6. Residue barrel
7. Base
8. Juicer jug



FEATURES

1. Large diameter juice extractor that allows an entire apple or pear to be inserted for juicing – easy, quick and hassle-free without having to slice them beforehand.
2. Simple and exclusive design with combined structure, easy to operate and clean.
3. High speed electric motor with overheating protection. High efficiency saves time and energy saving with high service motor life.
4. Specially designed safety lock unit for switching for added safety and reliability.

IMPORTANT SAFEGUARD

1. This machine features a safety lock. Your juice extractor will not operate when the handle does not fasten to the cover or the cutter seat is not fastened so as to ensure user safety.
2. When disassembling or assembling the juice extractor, press the upper cover of the feed port with your hand, then force the handle to slide in or out of cover slot.
3. When disassembling juicing net, first remove the cover and residue barrel. Turn the middle ring up to 30 degrees by holding juicing nozzle with your hand. Lift up the juicing net and it will automatically detach from the rotor.
4. Check your power supply for compliance with rated voltage first before using.
5. Clean all disassembled parts (refer to the section of "maintenance and cleaning").
6. Read the diagram carefully when assembling. Ensure that "name and position of main components" corresponds.
7. Read the "attention" section of the Instruction Manual carefully before using.

SPECIFICATIONS

MODEL	MJE-SC160W
RATED VOLTAGE / FREQUENCY	220-240V~ 50/60Hz
RATED WATTAGE	600W

WARNING

1. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
2. Before using, place this appliance on a stable and even table board, operate according to the above methods as instructed.
3. Before juicing ensure that the juicing net and rotor are correctly assembled position, and no hard contact exists between the juicing net cutter and transparent cover. Put the transparent cover on, secure the handle and turn power ON.
4. The appliance may emit a slight smell during first use. This is normal.
5. During juicing, ensure juices do not overflow or there is too much residue in the middle ring and residue cup. Turn off power, clean up and begin using again.
6. DO NOT open the cup cover during operation.
7. DO NOT insert fingers or any objects into the feed port to prevent an accident or damage to the appliance.
8. This appliance features an automatic overheating protection that will cut power to it when the appliance has been in use for a prolonged period or when it overheats. Should that happen, pull out the power plug from the power supply, wait for the motor to cool (about for 30 minutes) and use again.
9. DO NOT overload the appliance.
10. DO NOT empty the contents inside the appliance until the power plug is disconnected from the power supply.
11. DO NOT wash the cutter with your hands. Rinse them under a running tap as cutters are very sharp and may cut your hands.
12. DO NOT use this appliance for other than its intended use.
13. DO NOT use if the power cord is damaged or the power plug does not fit the socket safely. Contact your authorized service center for assistance.

CLEANING AND MAINTENANCE

1. Keep the appliance clean and dry to prolong its service life.
2. Store the appliance in a dry and well-ventilated place if it is not going to be used so as to prevent the motor from being damp and going moldy.
3. DO NOT immerse the base of the appliance in water or any other liquids. Wipe only with a wet cloth. Other components may be washed directly with water, such as pushing bar, cover, middle seat, residue cup, juice nozzle cover.