


Mórgan®


USER MANUAL



Jug Kettle

MJK-917

Mórgan®



E-mail: electrical.appliance@dksh.com
www.morgan.my

 facebook.com/morganappliances

C O N T E N T S

3 Important Safeguards

5 Parts Identification

5 Specifications

6 Operating Instructions

7 Care and Cleaning

Thank you for purchasing a quality MORGAN appliance. We trust that you will have a pleasant experience with your new product. To guarantee safety and best efficiency, please read this manual carefully and keep a copy for future reference.

IMPORTANT SAFEGUARDS

When using electric appliances, basic safety precautions should always be followed including the following:


1. Read all instructions carefully and retain them for future reference.
2. Before connecting to the power supply, ensure that the voltage of the appliance corresponds to the voltage indicated on the power supply rating label at the bottom of the appliance.
3. Close supervision is necessary when any appliance is used by or near children.
4. Do not touch hot surfaces. Use the handle or the button.
5. To protect against electric shock, do not immerse power cord, power plug, or any parts of the jug kettle in water or other liquids.
6. **WARNING:** Do not use the attached power base other for its intended purpose. Do not immerse power base in water or any other liquids.
7. Do not allow power cord to hang over edge of table or counter or touch hot surfaces.
8. Do not operate appliance with a damaged power cord or power plug or after the appliance malfunctions or has been damaged in any manner. In such a situation, it is recommended to return the appliance to your nearest Authorized Service Center for examination, repair, or adjustment.
9. Do not operate the appliance dry to avoid damaging the heat elements. Always ensure there is water inside the appliance before operating.
10. Should you accidentally operate the appliance without water, the boil-dry protection will automatically switch it off. Should this occur, allow the kettle to cool down before filling with cold water and re-boiling.
11. Do not place on or near a hot gas or electric burner or in a heated oven.
12. Ensure that kettle is used on a firm and flat surface where the children can't touch, this can prevent from overturning the kettle to damage the person or kettle.
13. **CAUTION:** Hot Water! Exercise caution when dispensing boiling water.
14. **CAUTION:** Avoid contact with escaping steam from the lid or spout when water is boiling or just after it has switched off.
15. Exercise extreme caution when moving an appliance containing hot water. Do not move the appliance when it is connected to the power supply.
16. The use of attachments that are not recommended by the appliance manufacturer may result in fire, electric shock or personal injury.

IMPORTANT SAFEGUARDS

17. Turn off power and detach power plug from the power supply when not in use and before cleaning. Allow it to cool before assembling or disassembling parts and before cleaning the appliance.
18. Always ensure the lid is closed and do not lift it while the water is boiling to prevent scalding.
19. If the kettle is overfilled, boiling water may be ejected.
20. This appliance is for indoor use only. Do not use outdoors.
21. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliances by a person responsible for their safety.
22. This appliance is intended to be used in household and similar applications such as:
 - Staff kitchen areas in shops, offices, farmhouses and other working environments;
 - Hotels, motels and other residential type environments;
 - Bed and breakfast type environments.
23. This appliance has a grounded power plug built in. Ensure that the power supply in your house is earthed.

PARTS IDENTIFICATION

1. Lid
2. Handle
3. Power Switch
4. Power Base
5. Water Level Indicator
6. Housing



SPECIFICATIONS

Model	MJK-917
Rated Voltage / Frequency	220-240V~ 50-60Hz
Rated Wattage	1850-2200W
Capacity	1.7L

BEFORE FIRST USE

If you are using the kettle for the first time, it is recommended that you clean your kettle before use by boiling a full kettle of water twice and then discarding the water.

1. To fill water into the kettle, detach it from the power base and open the lid by lifting the lid handle.
2. Fill with the desired amount of water into the kettle.
3. Always fill the kettle between the minimum (0.5L) and maximum (1.7L.) marks. Too little water will result in the kettle switching off before the water has boiled.
4. Close the lid. Attach the kettle onto the power base. Ensure the kettle contacts with the power base completely.
5. Connect the power plug into a power supply. Press down the switch to "I" position. The power light will illuminate, and water will begin boiling.
6. The kettle will switch off automatically once the water has boiled and the power light extinguishes. You can press the power switch to power off at any moment during boiling water.

NOTE: Do not fill the water over the maximum level, as water may spill out of the spout when boiling. Ensure that the lid is firmly in place before connecting the power cord to the outlet.

NOTE: Ensure that switch is clear of obstructions and the lid is firmly closed. The kettle will not turn off if the switch is constrained or if the lid is left open.

7. Lift the kettle from the power base to dispense water.
8. The kettle will not re-boil until the switch is released.
9. Allow kettle to cool for 15-20 seconds before reopening to boil water.
10. The kettle may be stored on the power base when not in use.

BOIL-DRY PROTECTION

Should you accidentally operate the kettle without water, the boil-dry protection will automatically switch it off. Should occur, allow the kettle to cool down before filling with cold water and re-boiling.

1. Always disconnect the appliance from the power outlet and leave it to cool down completely before cleaning.
2. Never immerse the kettle or cord in water or allow moisture to contact with internal parts.
3. Wipe the external housing with a mild and damp cloth or cleaner.
4. **CAUTION:** Do not use chemical, steel, wooden or abrasive cleaners to clean the appliance's exterior.
5. Use only a dry cloth to clean the power base.
6. Never use abrasive cleansing agents, petrol, solvents, etc. to clean the kettle and the power base.


DESCALING

1. Mineral deposits in tap water may cause the kettle interior to discolor.
2. To remove this build-up, use non-toxic Liquid Descaler.
3. It is recommended to remove water scale deposits regularly from inside the kettle based on how frequently the kettle is used.
4. Fill the kettle with 3 cups of white vinegar and add to water.
5. Allow to stand overnight. Do not boil.
6. Empty the solution from the kettle the next day.
7. Any stains remaining inside the spout can be removed by rubbing with a damp cloth.
8. Fill kettle with clean water, boil and then discard the water. Repeat and the kettle will be ready for use.

NOTE: HOT WATER! Exercise extreme caution when dispensing water.

Do not open the lid when water inside the kettle is hot to prevent scalding.

NOTE: Ensure power supply is turned off when kettle is not in use.



CORRECT DISPOSAL OF THIS PRODUCT

This marking shown on the product or its literature indicates that it should not be disposed with other household wastes at the end of its working life. In order to prevent any possible harm to the environment or human health from the uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where purchasing this product from or their local government office for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.